



Smithers AMS LLC
790 Main St
Wareham, MA 02571
License #: IL281355
Phone: 508-295-2550



Customer: The Healing Rose
Address:
23 Hale St
Newburyport MA 01950
Phone: 978-409-1091
License #: MDAR 25190109P



Sample ID: 3016
Sample Name: Silver CBD Oil
Sample Type: Other
Received Date: 11/07/2022
Report Date: 02/11/2023
METRC ID: N/A
Client Batch ID: Batch #1947
Client Sample Size: 30 mL
Unit Weight (g): 30

Results Summary

Cannabinoids

11/08/2022

TESTED

Microbial Impurities

11/10/2022

✓ PASS

Amended Report Notes


Revised cannabinoid distribution graph on page 1 for accuracy.

Certificate of Analysis

Amended 02/11/2023



Cannabinoid Distribution (%)



Disclaimer: The results presented within this report pertain only to the sample(s) indicated, as received by Smithers AMS LLC. Smithers AMS LLC is responsible for the information provided in this report, unless indicated that the customer provided the information. This report shall not be reproduced, except in full, without the written approval of Smithers AMS LLC. Action limits used to dictate pass/fail criteria are set by the Massachusetts Cannabis Control Commission.



Certificate of Analysis

Amended 02/11/2023

Cannabinoids

Date Started: 11/07/2022
Instrument: UPLC-PDA

Date Completed: 11/08/2022
Method: TP-09.001.03 & TP-09.012.03

Analyst: Yueming Wang Kovaleff
Deviation: N/A

Cannabinoid	Result (%)	Result (mg/g)	LOQ (%)
CBD	4.06	40.6	0.0474
CBG	0.167	1.67	0.00272
CBDV	0.0676	0.676	0.00218
CBDVA	ND	ND	0.00218
CBDA	ND	ND	0.00544
CBGA	ND	ND	0.00272
Δ9-THCV	ND	ND	0.00218
Δ8-THCV	ND	ND	0.00272
THCVA	ND	ND	0.00218
CBN	ND	ND	0.00272
CBNA	ND	ND	0.00218
Exo-THC	ND	ND	0.00218
Δ9-THC	ND	ND	0.00544
Δ8-THC	ND	ND	0.00272
CBL	ND	ND	0.00218
THCA-A	ND	ND	0.00544
CBC	ND	ND	0.00218
CBCA	ND	ND	0.00218
Total THC	ND	ND	
Total CBD	4.06	40.6	
Total Cannabinoids	4.29	42.9	

Total THC = Δ9-THC + Δ8-THC + (THCA-A x 0.877)

Total CBD = CBD + (CBDA x 0.877)

Total Cannabinoids = Sum of all cannabinoids without THC/CBD corrections.

LOD = Limit of Detection; **LOQ** = Limit of Quantitation; **ND** = Not Detected.

Microbial Impurities

 **PASS**

Date Started: 11/07/2022
Instrument: TEMPO & Gene-Up

Date Completed: 11/10/2022
Method: TP-09.010.01 & TP-09.011.01

Analyst: Elliot Henderson
Deviation: N/A

Microbials	Limit (CFU/g)	Status
Coliforms	1000	Pass
Bile-Tolerant Gram-Negative Bacteria	1000	Pass
Yeast & Mold	10000	Pass
Aerobic Bacteria	100000	Pass
E.coli		Pass
Salmonella		Pass



Eric Steele, Lab Director
 02/11/2023

END OF REPORT

Disclaimer: The results presented within this report pertain only to the sample(s) indicated, as received by Smithers AMS LLC. Smithers AMS LLC is responsible for the information provided in this report, unless indicated that the customer provided the information. This report shall not be reproduced, except in full, without the written approval of Smithers AMS LLC. Action limits used to dictate pass/fail criteria are set by the Massachusetts Cannabis Control Commission.